

Item Code: ELAS010X\_PEDW0150 | Rev.: 2019-07-22 | Ver: 3.0

# **MS FLEX MAXI**

## Single-component adhesive with a silanic termination (MS technology)

#### **¤**Description

MS FLEX MAXI is a single-component hydro-curing prepolymer based adhesive with a silanic termination (MS technology). Recommended for gluing of pre-finished wooden floor onto marble, grit, ceramic or marble-chip floor tiles, etc. Also suitable for gluing wooden floor onto underfloor heating and cooling system. MS FLEX MAXI has very good acoustic insulation characteristics. CERTIFICATES: EC1 PLUS, Ü-Mark of Conformity, heat conductivity (CSI test report n° 0013/DC/TTS/19).

MS FLEX MAXI can contribute to the achievement of QI CREDIT 4.1 according to the parameters of the GEV dated 03 March 2009, because it meets the certification LEED protocol (Leadership in Energy and Environmental Design).

#### **¤Characteristics**

single-component
+15°C ÷ +25°C
notched trowel N°5
1 h <i>መ</i>
36-48 h <sup>(1)</sup>
1,66 Kg/l ± 0,02
800-1400 g/m² depending on the
subfloor.
oak
9 months <sup>(2)</sup>
15 Kg
DILUENTE DS (before the
hardening of the adhesive)

- 1 at 20°C and 65% R.H.
- 2 in original sealed containers at temperatures between +10°C and +25°C

#### **ELaying** conditions

#### ♦ Subfloor

dry, clean, no-dust creating, not too rough.

#### ♦ Humidity of subfloor

2,0% max with cement subfloors.

1,7% max with radiant floor heating cement subfloors.

0,5% max with anhydrite subfloors.

 $0,\!2\%$  max with radiant floor heating anhydrite subfloors.

#### ♦ Wood humidity

9%±2

#### **#**How to use

The subfloor, according to local regulations, must be dry, free from cracks, uniform and completely clean from the elements that can damage its adherence. Apply MS FLEX MAXI paying attention to lay the wood blocks side by side and knock them down well to make sure the adhesive glues well to the entire surface. Perfect adhesion to the subfloor is ensured if at least 65% of each wooden component is in direct contact with the adhesive.

Subfloor with radiant floor heating, apply one coat of PRYMER SF 1105 (see technical data sheet) and after 24 hours proceed with the application of MS FLEX MAXI.

If the subfloor is porous or friable, we suggest to apply a coat of PRIMERFAST. The drying time for the subsequent coats depends on the primer used (see technical data sheets).

If you need to glue the wooden floor onto glazed subfloors (such as ceramic, enamelled tiles or polished marble, etc.) remove and clean the surface from dust, grit, glue and waxes. Apply by cloth the adhesion promoter LEVIGATORE LIQUIDO following the correct application time (see technical data sheet), then apply MS FLEX MAXI

Sand the surface of anhydrite subfloors thoroughly using 24 or 36 grit sandpaper; remove dust and apply primer using PRYMER SF 1105 (do not dilute) or PRIMERFAST (diluted with 30% of DMC 50). Even PRYMER PUB 77 can be applied on the anhydrite subfloors with DILUENTE DMC 50 in a 70:30 ratio.

MS FLEX MAXI must be acclimatized at room temperature before being applied. Sand the floor after 3-4 days, depending on the atmospheric conditions and humidity level of the wood species used. The possible excess of glue can be removed with a humid cleaning cloth. In case of left over, seal the bucket properly by using both lids to avoid waste.

#### Note:

Do not apply MS FLEX MAXI in presence of high evaporative fluxes as they cause the increase of pH of the substrate (pH>=10) and they cause problems with the screed/glue/wood system. In case of doubt apply one coat of PRYMER SF 1105 (see technical data sheet) and after 24 hours proceed with the application of MS FLEX MAXI

In order to have a stabilized and dried subfloor, after a proper ageing, it is necessary to test the sistem and we strongly recommended to follow exactly all the instructions of the radiant floor heating producers (we suggest to view the installation certificate). A not-fully seasoned and stabilized subfloor with radiant floor heating can release plasticizers (not fully cured) and residual humidity, that can compromise the adhesion properties of the glue during the time. It is important to follow the "Best conditions for laying wooden floors" as listed in this technical data sheet.

#### Shipping notes.

If the storage temperature exceeds +25°C, the time of storage is noticeably reduced, at temperatures above +50°C there is a real risk of thickening/gelatinization of the product even in the

These information are given from the best of our knowledge and technical experience. They are of general character and not binding in any way our company. Every single case should be put to a pratical test by the user who assumes the full responsability of the final result of his work.





Item Code: ELAS010X\_PEDW0150 | Rev.: 2019-07-22 | Ver: 3.

## **MS FLEX MAXI**

Single-component adhesive with a silanic termination (MS technology)

original packaging. For transport by sea it's advisable to use the special thermo-containers.

### **\*Warnings**

The subfloor should have a temperature of at least +12°C/+15°C. Do not apply the adhesive if the relative humidity of the room exceeds 75%. Do not lay wooden floor if the walls or ceilings are still wet after plastering or white-washing, etc. Never dilute the adhesive. Do not walk on the wooden floor for at least 24-36 hours after laying. Small quantities of methyl alcohol can be released during the drying phase.

# \*Label elements - Safety data sheet available on request.

These information are given from the best of our knowledge and technical experience. They are of general character and not binding in any way our company. Every single case should be put to a pratical test by the user who assumes the full responsability of the final result of his work.